





**Model No. : OEM-HYXZ Series**



**Flow Data**

Pump Head	Channel number	Tubing	ID×Wall thickness(mm)	mL/r (3 rollers)	mL/r (6 rollers)	Flow Rate(mL/min) (0.1-300rpm) (3 rollers)	Flow Rate(mL/min) (0.1-300rpm) (6 rollers)	Weight(kg)
HandyPump01	Single channel	13#	0.8×1.6	0.033	0.031	0.0033~10.03	0.0031~9.36	0.224 (3 rollers)
		14#	1.6×1.6	0.187	0.126	0.0187~56.09	0.0126~37.68	
		19#	2.4×1.6	0.371	0.215	0.0371~111.17	0.0215~64.51	
		16#	3.1×1.6	0.636	0.345	0.0636~190.76	0.0345~103.51	0.302 (6 rollers)
		25#	4.8×1.6	1.219	0.636	0.1219~365.69	0.0636~190.81	
HandyPump02	Dual channel	13#	0.8×1.6	0.033	--	0.0033~10.03	--	0.224 (3 rollers)
		14#	1.6×1.6	0.187	--	0.0187~56.09	--	
		19#	2.4×2.4	0.371	--	0.0371~111.17	--	
		16#	3.1×2.4	0.636	--	0.0636~190.76	--	






### Motor Specification

Model No.	Motor type	Power supply	Speed(rpm)	Speed error	Working environment
OEM-HYXZ001	37 DC planetary gear motor	DC24V	300	≤±10%	0-40°C, 80%RH
OEM-HYXZ002			200		
OEM-HYXZ003			100		
OEM-HYXZ101	37 DC planetary gear motor	DC12V	300		
OEM-HYXZ102			200		
OEM-HYXZ103			100		

### Dimension Drawing (Unit:mm)



### Tubing Installation Procedure



A. Turn the knob anticlockwise 180 ° , open the upper block.



B. Put the tube between rollers and upper block , tighten up the tubing lightly .



C. Turn the knob clockwise 180 ° , put the upper block back to original position , fasten the tube.